



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 3

TC720 Mitsubishi Shogun Pinin, Pinin Van 4Work & Pajero Junior 2000>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Side Arm	H	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	R/H Side Arm	J	4	M12 x 40 Bolts, 2 Nuts & 4 S/P Washers
D	2	Side Arm Extensions (5 door)	K	8	M12 x 40 x 1.25 Bolts & S/P Washers
E	2	Side Arm Straps	L	8	12 x 25 Flat Washers
F	1	Extension Bar	M	1	Socket Plate

1. Locate and remove the three existing bolts from the left hand chassis member
2. Remove fixings from lower edge of bumper. **Note:** on 5 door models, temporarily remove mud flaps (if fitted) and metal plates to gain easy access for bolts K and J.
3. Using Item K with Item L, loosely bolt Item E to the existing threaded hole on the inside face of each chassis member.
4. Using Item K with Item L, loosely bolt Item B and Item C to the existing threaded holes in the outer face of each chassis member. **Note:** on 5 door models, bolt Item D at the same time as Item B and Item C, and bolt to existing forward threaded hole using Item K with Item L.
5. Locate Item A between each chassis, and using Item J, bolt to Item E, and to Item B, and Item C.
6. Using Item H with Item L, bolt Item F and Item M to Item A
7. Using Item G, bolt the ball bracket (not supplied in this kit) to the mounting plate.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
9. Refit metal plates, mud flaps (where removed) and lower edge of bumper



Note: Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.