



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting



Issue 5

## TN2 NISSAN NOTE 2006> NISSAN MICRA 2003 - 2010

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	H	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Angle Side Arm	J	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	R/H Angle Side Arm	K	4	M12 x 40 Bolts, Nuts & S/P Washers
D	1	L/H Captive Clamp Plate	L	4	M10 x 40 Bolts & S/P Washers
E	1	R/H Captive Clamp Plate	M	5	M10 Nuts & S/P Washers
F	1	R/H Angle Bracket	N	9	10 x 25 Flat Washers
G	1	Extension Bar	P	4	12 x 25 Flat Washers
			R	1	Socket Plate

1. Remove rear bumper. Two fixings along lower edge, one tip fixing each side and four fixings along boot opening.
2. Remove the four fixings securing the plastic trim on the bottom edge of the rear panel.
3. Cut a section centrally from the lower edge of the bumper and plastic trim 65mm wide x 65mm deep (if required trim to suit).
4. Remove the two fixings securing the metal caps covering the openings to each chassis on the rear panel.
5. Check and clearance around chassis opening and trim if needed to ensure side arm angles sit flat.
6. Lower exhaust, for easy access to towbar mounting points.
7. Locate Item **B** into the left hand chassis and using Item **L** with Item **N** loosely bolt to the existing forward hole in the bottom face of the chassis.
8. Place Item **D** into the left hand chassis and locate the captive bolts into the holes in the side arm and loosely bolt using Item **M** with Item **N**, and bolt the remaining rearmost point with Item **L**, Item **M** and Item **N**
9. Place Item **E** into the right hand chassis and locate the captive bolts into the existing holes in the side face of the chassis, using Item **M** with Item **N** and loosely bolt Item **F** to the underside of the chassis..
10. Locate Item **C** into the right hand chassis and using Item **L** with Item **N** loosely bolt up through Item **F** and into the captive nuts in the side arm.
11. Using Item **K** bolt Item **A** to Item **B** and Item **C**.
12. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
13. Refit exhaust.
14. Refit bumper and plastic trim.
15. Using Item **J** with Item **P** bolt Item **G** and Item **R** to Item **A**.
16. Using Item **H** bolt the ball bracket (not supplied in this kit) to the mounting plate.

**Note:**

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

TN2

