



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 4

TR815 Renault Modus 2004>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	2	M16 x 40 Bolts, Nuts & S/P Washers
B	2	Side Plates	H	4	M10 x 90 Bolts, Nuts & S/P Washers
C	2	Clamp Plates	J	4	M12 x 40 Bolts, 2 Nuts & 4 S/P Washers
D	1	Extension Bar	K	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
E	2	17 x 59 R/H Spacer Bushes	L	4	12 x 25 Flat Washers
F	2	17 X 64 L/H Spacer Bushes	M	1	Socket Plate 1

1. Lower and remove the spare wheel.
2. Using item **H** with item **C** loosely bolt item **B** to the outer face of each chassis.
3. Locate the central and offside lower bumper support brackets and trim edges off. See sketch below.
4. Using item **J** loosely bolt item **A** to item **B**.
5. Using item **K** with item **L** bolt item **D** and item **M** to item **A**.
6. Using item **G** bolt the ball bracket (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. Replace Spare wheel.



Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.