



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 6

## TVV520 Volvo V70 Est 2000 - 2007

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Extension Bar	E	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	Heat Shield Plate	F	6	M12 x 40 Bolts & S/P Washers
			G	10	12 x 25 Flat Washers
			H	3	Rivets

1. Remove the battery cover from inside the boot.
2. Remove the rear bumper (four recessed nuts inside the boot along the rear panel). These nuts are located behind the foam covering. The foam has perforations to access the nuts. One rivet each side on the underside, drill these out. One torx head screw at the bumper tip. Pull out the top edge and slide the bumper off cut bottom edge of bumper 60mm x 85mm see sketch. Late 2004 facelift models bumper cut 60mm x 40mm, if required trim to suit.
3. Remove the towing eye from the right hand chassis member.
4. Remove the two bolts securing the rear exhaust hanger and one pop rivet on the heat shield. (The exhaust hanger is not refitted with the towbar).
5. Using item F with item G bolt item A to the existing captive nuts in each chassis member.  
**Note:** bolt item C to the forward left hand bolt to reattach the heat shield with a rivet supplied.
6. Replace the exhaust hanger onto the mounting point provided.
7. Fully tighten all bolts.
8. Re-fit the bumper using item H at the tips.
9. Using item E bolt item B to item A.
10. Using item D bolt the ball bracket (not supplied in this kit) to the mounting plate.



**Note:**

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.