



PRO-STEP™

Fitting Instruction



Issue 3

PRO-UNI

Item	Qty	Description
A	1	Universal PRO-STEP
B	2	M16 x 100 Bolts
C	2	M16 x 40 Flange Lock Bolts (10.9)
D	4	M16 Flange Lock Nuts (10.0)
E	1	SPACER-3

1. Using Item B with Item D bolt the ball bracket (Not supplied in this kit) and Item A to the Towbar face plate.
2. Using Item C with Item D bolt Item A through the remaining holes to the Towbar face plate.
3. Fully Tighten Fixings to 252Nm.
4. **All Four Heavy Duty M16 Lock Fixings Must Be used To Fit This Product.**

