



PRO-STEP™

Fitting Instruction



Issue 2

PRO-TIVE3-NT

Item	Qty	Description
A	1	PRO-TIVE3-NT STEP
B	2	Handed Side Arms
C	12	M12 x 40 Bolts & Nyloc Nuts
D	12	12 x 25 Flat Washers
E	12	12 x 40 Flat Washers
F	4	Black M12 Bolt Cap
G	2	8mm Spacer Plates

1. Locate four Towbar mounting points in each chassis member and pair up with the correct set of clamp plates (Item **G**).
2. Using Item **C** with Item **D** and Item **E** fix Items **B** to each correct chassis member ensuring Items **G** are sandwiched between Item **B** and the vehicles chassis.
3. Using Item **C** with Item **E** and Item **D** loosely assembly the fixing through the forward mounting point only leaving the fixing loose enough to enable you to slide Item **A** through the open slot.
4. Using Item **C** with Item **E** and Item **D** fix Item **A** to Item **B** through the remaining mounting point.
5. Fully tighten all fixings ensuring the Pro-Step is rigid, square and secure.

