




Tow-Trust Towbars

Tel: 01827 717412

Email: technical@tow-trust.co.uk



Issue 2

Kit 1 – Single Electrics With Buzzer Wiring Kit

| Item | Qty | Description | Item | Qty | Description |
|------|-----|------------------------|------|-----|-----------------------------------|
| A | 1 | 12N Pre-wired Socket | D | 1 | Ring Terminal |
| B | 1 | TEM1a (Audible Buzzer) | E | 1 | Self-tapping Screw |
| C | 10 | Blue Snap Connectors | F | 1 | 3 Metre Length Of Twin Core Cable |

1. Mount the pre-wired socket to your chosen socket plate (not supplied in this kit) using the screws provided.
2. Route the 7-core cable into the vehicle through a suitable grommet.

3. Connect the audible buzzer to the 7-core cable and the vehicles wiring loom as shown below;

| Wire Colour On Audible Buzzer | Connects To..... |
|-------------------------------|---------------------------------|
| Yellow | Yellow wire on 7 core cable |
| Green | Green wire on 7 core cable |
| Orange | Left Indicator Wire On Vehicle |
| Grey | Right Indicator Wire On Vehicle |
| White | Vehicle's Earth Point |

4. Connect the remaining wires from the 7 core cable to the vehicles wiring loom as shown below;

| Pin Number On 7 Pin Socket | Wire Colour | Connects to..... |
|----------------------------|-------------|--------------------------------|
| 2 | Blue | Fog Light Wire On Vehicle |
| 3 | White | Vehicle's Earth Point |
| 5 | Brown | R/H Side Light Wire On Vehicle |
| 6 | Red | Brake Light Wire On Vehicle |
| 7 | Black | L/H Side Light Wire On Vehicle |

5. Connect the white of the 7 core cable and white of the buzzer to the ring terminal supplied. Then fix to the vehicle's body either to an existing point or using the self-tapping screw provided.
6. Test all functions with suitable test equipment.