

Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting




Issue 2

TH254HK Honda CR - V 2002 - 2007

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	1	M12 x 25 Bolt & S/P Washers
B	1	Detachable Housing	H	8	M10 x 100 Bolts, Nuts & S/P Washers
C	2	Handed Side Arms	J	3	M12 x 22 Bolts & S/P Washers
D	1	15mm Spacer	K	4	M12 x 35 Bolts, 2 Nuts & 4 S/P Washers
E	1	12mm Spacer	L	1	M16 x 100 Bolt, Nut & S/P Washer
F	8	19 x 66 Spacer Tubes	M	8	10 x 40 Flat Washers
			N	4	12 x 25 Flat Washers
			P	8	10 x 25 Flat Washers
			R	2	10mm Spacers
			S	1	HK Socket Plate

1. Temporarily lower the rearmost exhaust.
2. Remove trim from the boot.
3. Locate the four dimples each side in the boot floor. Drill out to 20mm. Pass 11mm drill down through the freshly drilled holes and locate in the dimples below and drill down through the bottom face.
4. From inside the boot locate Item F down through each hole into the chassis.
5. Using Item H with Item P and Item M inside the boot loosely bolt Item C into place. Note: to give maximum clearance above the exhaust on the right hand side, insert bolts from underneath.
6. Using Item K loosely bolt Item A to Items C.
7. Locate Item D, E and Item R either side of the central towing eye and using Item L bolt into place SEE SKETCH.
8. Using Item J with Item N and Item G with Item N bolt Item B and Item S to Item A.
9. Fully tighten all nuts and bolts and ensure the Towbar is rigid and secure.
10. Refit exhaust and replace boot trim.



Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.